

**Agence Nord:**  
 ZA Object'ifs Sud - Lot A3  
 6 Allée Emilie du Châtelet  
 14123 lfs  
 tél : 02.31.34.50.74  
 fax : 02.31.34.55.17



**Agence Est:**  
 Parc Club des Tanneries  
 2 Rue de la Faisanderie  
 67380 Lingolsheim  
 tél : 03.88.04.01.81  
 fax : 03.68.93.01.52

**Agence Sud:**  
 Bât Le Venango, 392 Rue Jean Dausset  
 AGROPARC - BP11575  
 84916 Avignon Cédex 9  
 tél : 04.90.27.17.95 fax : 04.90.27.17.52

www.deltalabo.fr  
 info@deltalabo.fr



## Features of the EMCEE Model 1152 DIGITAL CONDUCTIVITY METER (ASTM Standard Test Method D 2624)

### EMCEE

### DIGITAL

### CONDUCTIVITY

### METER

convenient  
 reliable  
 accurate  
 measurement  
 of  
 electrical  
 conductivity

- Continuous standard electrical conductivity range from 0 to 1999 in increments of 1 picosiemen per meter (pS/m)
- Available in other standard and non-standard conductivity ranges
- Large digital, liquid crystal display
- Reliable advanced integrated circuit design technology
- Self check calibration with field adjustment capability
- Automatic over range and low battery indication
- Capable of storage tank and tanker truck measurement with the use of a short cable or cable reel kit
- Powered by 3 readily available alkaline batteries
- Electronics housed in a rugged cast aluminum case coated with solvent resistant paint equipped with a detachable stainless steel probe
- Approved intrinsically safe design for use in hazardous environments by Underwriters Laboratories (UL), Canadian Standards Association (CSA), and LCIE

### APPLICATIONS

The Model 1152 Digital Conductivity meter provides a measurement of electrical conductivity of fluids in conductivity units (CU), which are defined as picosiemens per meter in ASTM D 2624. The rugged Electro/mechanical design of the Model 1152 meter facilitates ease of use for both laboratory and field applications. Initially the meter was designed and developed for safety reasons to measure the electrical conductivity of hydrocarbon fuels, particularly jet fuels. Subsequently, The meter was modified with other conductivity ranges to accommodate measurement of a variety of fluids for different applications.

**Safety** - Hydrocarbon fuels typically have low electrical conductivity and consequently, are susceptible to retaining a static charge. Static charges are induced, especially, when the fuel is pumped at high rates through filters. Due to the relatively low conductivity, the static charge does not readily dissipate and is retained for a considerable period of time. This condition can result in an explosion and/or fire. Since

### Specifications:

<b>Range:</b>	0 - 1999 pS/m
<b>Resolution:</b>	1 pS/m
<b>Accuracy:</b>	2% of reading ± 1 pS/m
<b>Over-Range Indicator:</b>	"1" on left side of display
<b>Calibration:</b>	Internal source, field adj.
<b>Controls:</b>	2 Pushbuttons, "M" (measure) & "C" (calibration)
<b>Display:</b>	Liquid crystal, 3 ½ digits, ½ inch (.27 cm) high
<b>Safety Ground:</b>	Banana jack on electronics assy.
<b>Power:</b>	Battery, 3 each, 6 volt alkaline
<b>Op Temp Range:</b>	32° to 165° F (0° to 75° C)
<b>Carrying Case:</b>	Hard, solvent resistant, molded plastic

**Theory of Operation** - The EMCEE Model 1152 meter consists of an electronics assembly and a detachable stainless steel probe. The probe, which is similar to a capacitor having concentric electrodes, is immersed into the fluid, up to the set of holes closet to the electronics assembly. Depressing the "M" pushbutton causes a relatively small direct current to flow through the fluid between the electrodes. The current is amplified in the electronics assembly and is displayed on the liquid crystal display in picosiemens



Model 1152 Meter



Cable Reel Kit



Detachable Probe